

TeleTech SYSTEM SELECTION - four decisions to make...

1) PSTN or GSM installation? 2) "On-Lift" or Stationary/Central GSM mounting? 3) "Drop and Go" or "In Panel" installation? 4) Number of lifts covered by one telephone rental?

PSTN "On-Lift" with only <i>one</i> standard telephone line				GSM "On-Lift" with only <i>one</i> SIM card				GSM Stationary/Central with only <i>one</i> SIM card	
"Drop and Go"		"In Panel"		"Drop and Go"		"In Panel"		"Drop and Go"	"In Panel"
<u>1 Lift:</u> 1 x AutoDial TSA5100 PSTN	<u>2 to 8 Lifts:</u> 1 x LineSaver ALC10 + up to 8 x AutoDial TSA5100 PSTN	<u>1 Lift:</u> 1 x VoicePilot TSA2100 PSTN	<u>2 to 8 Lifts:</u> 1 x LineSaver ALC 10 + up to 8 x VoicePilot TSA2100 PSTN	<u>1 Lift:</u> 1 x AutoDial TSA5110 GSM	<u>2 to 8 Lifts:</u> 1 x AutoDial TSA5110 GSM (as master) + up to 7 x AutoDial TSA5100 SLAVE	<u>1 Lift:</u> 1 x VoicePilot TSA2110 GSM	<u>2 to 8 Lifts:</u> 1 x GsmMaster TSI1110 + up to 8 x VoicePilot TSA2100 SLAVE	<u>1 to 8 Lifts:</u> 1 x GsmMaster TSI1110 + up to 8 x AutoDial TSA5100 SLAVE	<u>1 to 8 Lifts:</u> 1 x GsmMaster TSI1110 + up to 8 x VoicePilot TSA2100 SLAVE

Note:

TSI110, TSA2100 and TSA2110 not released yet

Explanation of terms:

PSTN =	(Public Switched Telephone Network) – a standard wired telephone line
GSM =	(Global System for Mobile communication) – a typical mobile telephone standard
SIM card =	(Subscriber Identity Module card) – a miniature identification card typically for mobile phones
"On-Lift" mounting =	Alarm unit physical placed in or on the elevator cabin
"Stationary/Central" mounting =	Alarm unit physical placed for example in the machine room
"Drop and Go" =	A TeleTech concept which means fast installation of an alarm unit on the top of the elevator cabin
"In Panel" =	A TeleTech concept which means installation of an alarm unit in the elevator cabin - either behind elevator panel or in the front of the elevator panel



AutoDial TSA5100 PSTN



AutoDial TSA2100 PSTN



AutoDial TSA5110 GSM



LineSaver ALC10



GsmMaster TSI1110